



Einhell

CLASSIC



Cordless Lawn Trimmer GC-CT 18/24 Li P (1x1,5Ah)

Item No.: 3411102

Ident No.: 11017

Bar Code: 4006825626575

The Einhell GC-CT 18/24 Li P (1x1.5Ah) cordless grass trimmer is the ideal helper for bringing the garden and strips of grass into shape. Equipped with an 18 V / 1.5 Ah lithium-ion battery from the Power X-Change series, the grass trimmer has an operating time of up to 40 minutes. 3 LEDs show the charge status at a glance. The rechargeable battery can also be used in all other devices from the system series. For comfortable working without fatigue there is an additional handle for two-handed operation. The housing and the secondary handle are made of impact-proof, high-grade plastic. The cutting width is 24 cm with a speed of 8,500 rpm. Complete with one 1.5 Ah PXC rechargeable battery, one PXC charger and 20 plastic blades.

Features & Benefits

- Incl. 1x Power X-Change system battery (1,5Ah)
- Battery capacity indicator with 3 LEDs
- Akku can be used for all the tools in the Power X-Change family
- System charger included
- Incl. 20 plastic blades
- User-friendly two-hand operation thanks to additional handle
- Housing and handle made of impact-resistant, high-grade plastic

Technical Data


- Accumulator 18 V | 1.5 Ah | Li-Ion
- Max. running time 40 min
- Charging time 2h
- Revolutions of knife 8500 rpm
- Cutting width of knife 24 cm
- Number of accumulators 1 Pieces

Logistic Data

- Product weight 1.57 kg
- Gross weight single packaging 2.39 kg
- Dimensions single packaging 180 x 150 x 490 mm
- Pieces per export carton 8 Pieces
- Gross weight export carton 22 kg
- Dimensions export carton 635 x 505 x 390 mm



20 x



Available as special accessories



Spare Blade-set PXC Trimmer
Lawn Trimmer Accessory
Item No.: 3405730
Bar Code: 4006825560404
Einhell Grey



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 trimming ¹ (min.)
1.5 Ah	40
2.0 Ah	55
2.5 Ah	65
3.0 Ah	80
4.0 Ah	125
5.2 Ah	160
6.0 Ah	180
8.0 Ah	250

Test setup:

1) lawn