







Universal Spreader

GE-US 18 Li-Solo

Item No.: 3415410

Ident No.: 11018

Bar Code: 4006825638356

The Einhell Universal Spreader GE-US 18 Li is a handy helper for jobs all-year round at home, in the garden or in outdoor spaces. It can be used e.g. to spread fertilizer, lawn seed or de-icing salt. The spreader is powered with an 18 V Power X-Change battery, which can be used in all devices in this range. The 6-level electronic speed control and the 8-level, ergonomic spreading volume control deliver perfectly dosed spreading performance. The container has a capacity of 3.3 l. Here, the spreading width can be individually adjusted to a maximum of five meters. The softgrip handle is ergonomically designed. The product is supplied without batteries or a charger. These are available separately, for example as an Einhell PXC starter set.

Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- 6-stage electronic speed control
- 8-stage, ergonomic flow rate adjustment knob
- 3.3I filling capacity
- Ergonomic and secure handling thanks to softgrip
- Individually adjustable spread width (max. 5m)
- Spreading of fertiliser, grass seed and even salt
- Year round use for spreading fertiliser, grass seed and salt
- Supplied without battery and charger (available separately)

Technical Data

800 m² - Max. surface capacity 3.3 L - Capacity of grit box

Logistic Data

- Product weight 1.24 kg - Gross weight single packaging 1.78 kg

280 x 225 x 305 mm - Dimensions single packaging

- Pieces per export carton 4 Pieces 7.9 kg - Gross weight export carton

578 x 446 x 330 mm - Dimensions Export Carton - Container quantity (20"/40"/40"HC) 2800 | 1360 | 3232





















Available as special accessories



18V 2,0Ah Power X-Change Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042

Bar Code: 4006825613704



Einhell Accessory

Power X-Twincharger 3A

Charger Item No.: 4512069

Bar Code: 4006825629729

Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376

Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437

Bar Code: 4006825616606

Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit

Item No.: 4512040 Bar Code: 4006825613681

Einhell Accessory

Battery-Running-Times



One Battery for All	running time 1 (h)
1.5 Ah	2
2.0 Ah	3
2.5 Ah	4
3.0 Ah	6
4.0 Ah	7
5.2 Ah	9
6.0 Ah	10
8.0 Ah	14

Test setup:

1) -