



# Einhell

# EXPERT

## POWER X-CHANGE

Cordless Lawn Edge Trimmer

**GE-LE 18/190 Li-Solo**

**Item No.: 3424300**

Ident No.: 21022

Bar Code: 4006825651287

The Einhell GE-LE 18/190 Li-Solo cordless lawn edge trimmer is a member of the clever PXC family. For precise results between 36.5 mm to 45 mm there is an adjustable depth setting facility with 3 levels. The twin-bladed cutter delivers perfect results when cutting borders, and exact progress along the lawn is assured by the rollers at the front/back. The soft grip guarantees optimum handling and ergonomics. The adjustable additional handle ensures that the cordless lawn edge trimmer can be guided precisely and safely. The split shaft makes it easy to transport and stow away in minimum space. 1 x 18 V PXC rechargeable battery is needed for operation. The product is supplied without a battery or charger which are available separately.

## Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- 3-steps cutting depth adjustment for precise working results
- Double cutting blade delivering perfect cutting of the edges
- Split Shaft - easy transport and space-saving storage
- Softgrip ensuring perfect handling and ergonomics
- Adjustable additional handle - easy and safe handling
- Guide wheels (front/back) providing accurate working progress
- Knife protection cover guarantee full safety while working
- Supplied without battery and charger (available separately)

## Technical Data

- Min. cutting depth 36.5 mm
- Max. cutting depth 45 mm
- cutting depth adjustment 3 settings

## Logistic Data

- Product weight (kg) 3.05
- Gross weight (kg) 4.65
- Dimensions single packaging 300 x 180 x 920 mm
- Pieces per export carton 2 Pieces
- Gross weight of export carton 9.8 kg
- Dimensions export carton 940 x 315 x 370 mm
- Container quantity (20"/40"/40"HC) 504 | 1032



BATTERY & CHARGER NOT INCLUDED



CENTRAL DEPTH ADJUSTMENT



SPLIT SHAFT



GUIDE WHEELS



DUAL GRIP



ADDITIONAL HANDLE




BATTERY & CHARGER

NOT INCLUDED



18 V



3x  
EDGING  
DEPTH  
ADJUSTMENT



SPLIT SHAFT

## Available as special accessories



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Spare Blade GE-LE 18/190 Li  
Lawn Trimmer Accessory  
Item No.: 3405101  
Bar Code: 4006825653533  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB  
Battery  
Item No.: 4511524  
Bar Code: 4006825656206  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



5,2Ah & 4A Fastcharger  
PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



PXC Akku-Wandhalterung  
Case  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory

# Battery-Running-Times

One Battery for All	 trimming <sup>1</sup> (min.)
1.5 Ah	20
2.0 Ah	25
2.5 Ah	33
3.0 Ah	45
4.0 Ah	55
5.2 Ah	65
6.0 Ah	75
8.0 Ah	110

**Test setup:**

1) lawn