



Einhell

EXPERT

POWER X-CHANGE

Cordless Fan

GE-CF 18/2200 Li

Item No.: 3408035

Ident No.: 21011

Bar Code: 4006825665253

The Einhell cordless fan TE-CF 18/2200 Li is a breath of fresh air. The cordless device can be used anywhere, ensuring air supply or distribution of air flows. The fan is a member of the Power X-Change family. The battery can be used in more than 200 Einhell devices. Compact and portable, the cordless fan is intended for both outdoor and indoor use. The adjustment on the fan head is infinitely variable. Thanks to numerous fastening options, use is universal. There are three stages for adjusting the air flow. Up to 18 hours of battery life possible with a 5.2 Ah PXC battery. Delivery does not include battery or charger (sold separately).

Features & Benefits

- A member of the Power X-Change family, 1x 18V batteries required
- Compact, portable cordless fan for indoor and outdoor use
- Infinitely variable adjustment of the fan head
- Universal use thanks to numerous fastening options
- 3 settings for adjusting the air flow
- Runs for up to 18 hours with one 5.2 Ah PXC battery
- Supplied without a battery and charger (available separately)

Technical Data

- | | |
|-------------------|-------------------------------|
| - No-load speed | 2200 - 1200 min ⁻¹ |
| - Wind speed | 15000 m/h |
| - Fan diameter | 180 mm |
| - Swiveling range | 0 - 360 ° |

Logistic Data



Available as special accessories



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 blowing ¹	 blowing ²
	(h)	(h)
1.5 Ah	5.3	2
2.0 Ah	7	2.6
2.5 Ah	8.8	3.3
3.0 Ah	10.6	4
4.0 Ah	14	5.6
5.2 Ah	18.3	7
6.0 Ah	21.2	8
8.0 Ah	28	11.2

Test setup:

1) Min. electronic speed

2) Max. electronic speed