



Einhell

EXPERT PLUS



Cordless Vacuum Cleaner

TE-VC 18 Li-Solo

Item No.: 2347120

Ident No.: 21031

Bar Code: 4006825612646

The Einhell TE-VC 18 Li-Solo cordless hand vacuum cleaner is a convenient powerhouse of the Power X-Change family. The same rechargeable battery can be used in all PXC devices. Every surface and crevice can be thoroughly cleaned thanks to the individual nozzles. The floor nozzle is suitable for smooth surfaces. A second nozzle is provided for upholstery and fabrics. Hard-to-reach areas can be cleaned effortlessly using the crevice nozzle. Use the 46.5 cm extension tube when you want to clean the floor using the handheld vac as a floor vacuum cleaner. The dust container has a capacity of 540 ml. For space-saving storage there is an integrated wall bracket. The product is supplied without a battery & charger which are available separately.

Features & Benefits

- A member of the Power X-Change family, 1x18V battery necessary
- Dust container with a volume of 540 ml
- Cleaning the filters under running water
- Incl. floor nozzle for hard floors and smooth surfaces
- Incl. crevice nozzle for hard to reach areas
- Incl. upholstery nozzle for cleaning upholstery and fabrics
- Incl. extension tube (46.5 cm) for cleaning floors
- Space-saving storage thanks to the integrated wall bracket
- Supplied without battery and charger (available separately)



Technical Data

- Suction power max. 42 mbar
- Suction volume 13.5 L/s
- Volume 0.54 L
- Length of suction tube 46.5 cm
- Diameter of suction tube 32 mm
- Sound pressure level Lpa 68 dB (A)



Logistic Data

- Product weight 0.85
- Dimensions single packaging 472 x 130 x 193 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 7.7 kg
- Dimensions Export Carton 490 x 290 x 410 mm
- Container quantity (20"/40"/40"HC) 1920 | 4000 | 4700



Available as special accessories



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 vacuuming ¹ (min.)
1.5 Ah	12
2.0 Ah	16
2.5 Ah	18
3.0 Ah	23
4.0 Ah	31
5.2 Ah	40
6.0 Ah	46
8.0 Ah	62

Test setup:

1) no-load