



Einhell

CLASSIC



Cordless Radio

TC-RA 18 Li BT - Solo

Item No.: 3408017

Ident No.: 21010

Bar Code: 4006825651492

The Einhell cordless radio TC-RA 18 Li BT is a practical member of the powerful Power X-Change family. The handy and robust radio receives both on AM and FM frequency, 10 memory slots are available for each. Using Bluetooth, the cordless radio can easily be paired with the smartphone, which can also be safely stored on the back of the device. The intuitive operating options are located around the high-quality LCD display with time display. The foldable antenna ensures space-saving storage and easy transport by means of a carrying handle. In addition, the radio has the option of wall mounting. Delivery does not include a battery or charger, but these are available separately.

Features & Benefits

- A member of the Power X-Change family
- AM and FM reception with 10 memories each
- Bluetooth for convenient radio and smart phone connection
- Robust and user-friendly cordless radio
- Intuitive operating options around the display
- High-quality LCD display with time display
- Fold-down antenna for space-saving storage
- Practical carry-handle for transport and handling
- Can be easily mounted on the wall
- Storage area at the back for a smart phone, etc.
- Supplied without battery and charger (available separately)





Technical Data

- Frequency AM 522 - 1620 kHz
- Frequency FM 87.5 - 108 MHz
- Number of station presets (AM/FM) 10 / 10

Logistic Data

- Tool weight 0.7 kg
- Gross Weight 0.89 kg
- Pieces per export carton 4 Pieces
- Gross weight of export carton 3.86 kg
- Dimensions Export Carton 330 x 220 x 250 mm
- Container quantity (20"/40"/40"HC) 5376 | 11072 | 12456



Available as special accessories



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 running time ¹ (h)
1.5 Ah	12
2.0 Ah	16
2.5 Ah	20.5
3.0 Ah	24.5
4.0 Ah	32.5
5.2 Ah	42.5
6.0 Ah	49
8.0 Ah	65

Test setup:

1) -