



# Einhell

# EXPERT

## POWER X-CHANGE

**Cordless All Purpose Saw**

**TE-AP 18/22 Li-Solo**

**Item No.: 4326300**

Ident No.: 21031

Bar Code: 4006825601381

The TE-AP 18/22 Li – Solo cordless universal saw is the smallest saw of its class and a versatile tool which demonstrates its strong points on a wide spectrum of sawing jobs, whether at construction site, in the workshop or in the garden. This particularly light and handy saw is equipped with a unique Triathlon motor for providing excellent power, speed and efficiency. The tool is supplied without battery and charger but it can be powered by Power X-Change rechargeable batteries.

## Features & Benefits

- Member of the Power X-Change family
- Versatile: Building site - workshop - garden
- The smallest universal saw of its class
- Unique Triathlon motor (powerful, fast, efficient)
- Blade change without tools
- Adjustable soleplate for optimum blade use
- Ergonomic softgrip surfaces
- Rubber supports to protect the housing
- Supplied without battery and charger (available separately)
- Incl. saw blade for wood




## Technical Data

- Number of strokes 0 - 2600 min<sup>-1</sup>
- Stroke height 22 mm
- Cutting depth in wood 100 mm
- Cutting depth in steel 6 mm
- Toolless saw blade change yes

## Logistic Data

- Product weight 1.6 kg
- Gross weight single packaging 2.02 kg
- Dimensions single packaging 415 x 80 x 165 mm
- Pieces per export carton 6 Pieces
- Gross weight export carton 12.5 kg
- Dimensions export carton 430 x 260 x 352 mm
- Container quantity (20"/40"/40"HC) 4260 | 8520 | 10200



## Available as special accessories



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Sabersaw-bl. set 3pc W/M Batt  
All Purpose Saw Accessory  
Item No.: 49576105  
Bar Code: 4009315761053  
KWB by Einhell



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 sawing <sup>1</sup> (pieces)
1.5 Ah	140
2.0 Ah	185
2.5 Ah	240
3.0 Ah	290
4.0 Ah	370
5.2 Ah	570
6.0 Ah	580
8.0 Ah	740

### Test setup:

1) wood - round soft wood Ø 35 mm