



Cordless All Purpose Saw

TE-AP 18/28 Li BL - Solo

Item No.: 4326310 Ident No.: 21021

Bar Code: 4006825644951

The Einhell TP-AP 18/28 Li BL - Solo cordless reciprocating saw is a member of the Power X-Change series . Each rechargeable battery in the system can be combined with any PXC device. The brushless motor offers more power and runs for longer, while the anti-vibration function ensures low vibration while working. The soft grip surfaces make the saw ergonomic to handle. The rotatable main handle ensures maximum flexibility. The adjustable soleplate enables optimal use of the blade, and tool-less blade changes keep things simple. A quality wood blade from KWB is included in the scope of delivery. This product comes without a battery or charger. We recommend at least 2.5 Ah.

Features & Benefits

- A member of the Power X-Change family
- Brushless motor more power and prolonged operation
- Rotatable main handle for maximum flexibility
- Anti-vibration function ensures low vibration during operation
- Adjustable soleplate for optimum blade use
- Tool-less blade changes for rapid application
- Ergonomic handling thanks to soft grip surfaces
- For optimum results: rechargeable battery, 2.5 Ah or more
- Supplied without battery and charger (available separately)
- Incl. KWB quality blade (wood)

Technical Data

-	Number	of	strokes

- Stroke height
- Cutting depth in wood
- Cutting depth in plastic
- Cutting depth in steel
- Toolless saw blade change

Logistic Data

- Product weight
- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

2.06 kg 2.71 kg 445 x 175 x 110 mm 4 Pieces 11.85 kg 460 x 370 x 240 mm 2664 | 5484 | 6656

0 - 2500 min^-1

28 mm

200 mm


20 mm

12 mm

ves









Available as special accessories







18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory

Bar Code: 4009315761053 KWB by Einhell

2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509

18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097

Bar Code: 4006825646962

18V 4,0Ah Power X-Change 1

Bar Code: 4006825610376

Sabersaw-bl. set 3pc W/M Batt All Purpose Saw Accessory Item No.: 49576105

Einhell Accessory

Einhell Accessory

Item No.: 4511396

Einhell Accessory

Battery



Power X-Car Charger 3A Charger Item No.: 4512113

Einhell Accessory

Item No.: 4511489 Bar Code: 4006825638578 **Einhell Accessory**

Einhell Accessory

Battery

Bar Code: 4006825655377

Power X-Boostcharger 6A

Charger Item No.: 4512064 Bar Code: 4006825629019

2x18V 4,0Ah PXC-Twinpack CB 1







18V 3,0 Ah Power-X-Change 2 Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



















18V 3,0Ah Power X-Change Plus Einhell Accessory

18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory

18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 **Einhell Accessory**

18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit

Bar Code: 4006825613704

Item No.: 4512042

Einhell Accessory



Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory Power X-Fastcharger 4A

Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 **Einhell Accessory**

18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 **Einhell Accessory**

Battery Item No.: 4511501 Bar Code: 4006825644197

GS mark belongs to the product itself only, excluded accessory Page 2

Battery-Running-Times

One Battery for All	sawing ¹ (pieces)
1.5 Ah	170
2.0 Ah	226
2.5 Ah	332
3.0 Ah	417
4.0 Ah	556
5.2 Ah	723
6.0 Ah	834
8.0 Ah	1112

For best performance select a battery with at least 2.5 Ah

Test setup:

1) softwood - round soft wood Ø 35 mm