



EXPERT

Cordless Circular Saw

TE-CS 18/165-1 Li - Solo

Item No.: 4331207 Ident No.: 21021

Bar Code: 4006825647556

The Einhell cordless TE-CS 18/165-1 Li-Solo handheld circular saw is compact, light and easy to work with, and it is a member of the Einhell Power X-Change family. The high-performance lithium-ion batteries are used in all Power X-Change products. You can adjust the cutting depth and tilt angle on the hand-held circular saw without any tools. A spindle lock makes it easy to swap sawblades with a 20 mm bore. High-quality LEDs and a dust vacuum attachment give you a clear view of what you are doing and keep the work area clean. The TE-CS 18/165-1 Li-Solo is compatible with the Einhell guide rail which is available separately. The saw is supplied without a battery and charger which are available separately.

Features & Benefits

- A member of the Power X-Change family
- Small, light and handy for comfortable operation
- Easy adjustment without tools (cutting depth, tilt angle)
- Dust extractor adapter to keep the workplace clean
- Compatible with the Einhell guide rail
- Easy changing of the saw blade thanks to the spindle lock
- High quality aluminium base plate
- Sawblades with 20mm core can be used
- High quality sawblade is included in delivery
- High-quality LED for optimum illumination of the cutting area
- Supplied without battery and charger (available separately)



- No-load speed
- Saw Blade
- Number of saw teeth
- Cutting depth at 90°
- Cutting depth at 45°

Ø165 x Ø20 mm 18 Pieces 54 mm 35 mm

4200 min^-1

Logistic Data


- Product weight
- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)











Available as special accessories



Guide Rail Alu 2x1000mm Circular Saw Accessory Item No.: 4502118 Bar Code: 4006825632675 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory

18V 2,0Ah Power X-Change

Bar Code: 4006825610369

Item No.: 4511395

Einhell Accessory

Battery





18V 4.0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory













Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory 2x18V 4,0Ah PXC-Twinpack CB 1 Battery

18V 5,2Ah Power X-Change Plus

Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory

2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083

Bar Code: 4006825638509

18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097

Bar Code: 4006825646962

Bar Code: 4006825610376

18V 2,5Ah Power X-Change

Bar Code: 4006825650518 Einhell Accessory

18V 4,0Ah Power X-Change 1

Einhell Accessory

Einhell Accessory

Item No.: 4511396

Einhell Accessory

Battery Item No.: 4511516

Battery

Battery

18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory

Battery-Running-Times

	se de la constance de la const
One Battery for All	sawing ¹ (m)
1.5 Ah	25
2.0 Ah	33
2.5 Ah	40
3.0 Ah	49
4.0 Ah	64
5.2 Ah	82
6.0 Ah	98
8.0 Ah	128

Test setup:

1) wood - chipboard 19 mm