



Einhell

EXPERT

POWER X-CHANGE

Cordless Biscuit Joiner

TE-BJ 18 Li - Solo

Item No.: 4350630

Ident No.: 21011

Bar Code: 4006825660302

As a member of the Power X-Change family the Einhell TE-BJ 18 Li cordless biscuit joiner is flexible, can be used independently of a power source and is ready for immediate use. The solid aluminium design enables precise cutting of slots and is suitable for all standard sizes up to type 20. Infinitely adjustable alignment options for both the height setting and angle setting up to 90° degrees and the 6-step quick adjustment of the cutting depth are winning features of this flexible helper. The spindle lock enables cutters to be changed with ease. Delivery includes a face spanner and a dust bag. Thanks to the extractor adapter, it is also compatible with Einhell wet & dry vacs

Features & Benefits

- A member of the Power X-Change family
- Cordless cutting – flexible, independent and ready for use
- Infinitely adjustable angle setting up to 90°
- Infinitely adjustable height setting
- 6-step quick adjustment of cutting depth
- Suitable for standard biscuit dowel sizes up to type 20
- Solid aluminium design enables precise cutting of slots
- Spindle lock for easy cutter change
- Face spanner for cutter change
- Complete with dust bag for dust-free working
- Also compatible with Einhell wet & dry vacuum cleaners
- Supplied without a battery or charger (available separately)




Technical Data

- Voltage 18 V
- Idle speed 6500 min⁻¹
- Groove cutter Ø100 x Ø22 x 4 mm
- Max. router depth 2 cm
- Tilt angle adjustment 90 °



Logistic Data

- Product weight (kg) 2.58
- Gross weight (kg) 3.38
- Dimension single carton 390 x 200 x 180 mm
- Pieces per export carton 3 Pieces
- Gross weight of export carton 10.8 kg
- Dimension export box 615 x 415 x 200 mm
- Container quantity (20"/40"/40"HC) 1680 | 3390 | 4005



Available as special accessories



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 cutting ¹ (number of)
1.5 Ah	212
2.0 Ah	283
2.5 Ah	353
3.0 Ah	424
4.0 Ah	566
5.2 Ah	735
6.0 Ah	840
8.0 Ah	1132

Test setup:

1) softwood - pine wood