



Cordless Rotating Sander

TE-RS 18 Li-Solo

Item No.: 4462010 Ident No.: 21031 Bar Code: 4006825618341

The Einhell cordless rotating sander TE-RS 18 Li - Solo provides the user with independent flexibility for work in the home, garage & workshed. Speed electronics enables the tool to be adjusted to the material/application on different surfaces. Finest finish and a high sanding performance can be achieved thanks to the eccentric concept. For safe & comfortable operation there is a soft grip. A hook and loop fastening ensures that the abrasive paper is held securely. A dust extractor is included to keep the work area dust-free, an external dust extractor can also be connected. Complete with one piece of abrasive paper (P80). It is a member of the Power X-Change series. The battery and charger are available separately.

Features & Benefits

- Member of the Power X-Change family
- Speed electronics for material and application suitable working
- Finest finish & high sanding performance due to eccentric concept
- Safe and comfortable operation thanks to the soft grip
- Hook and loop fastening for holding the abrasive paper securely
- Both integrated and connection for external dust extraction
- Incl. 1x abrasive paper (P80)
- Supplied without battery and charger (available separately)

Technical Data

- Oscillating speed	14.000 - 22.000 min^-1	
- Oscillating circuit	2 mm	
 backing pad diameter 	125 mm	
- Sanding paper diameter	125 mm	
- Idle speed	7000 - 11000 min^-1	


Logistic Data

- Product weight (kg)
- Gross weight (kg)
- Dimensions single packaging
- Pieces per export carton
- Gross weight of export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

1.15
1.49
180 x 150 x 180 mm
8 Pieces
12.3 kg
630 x 190 x 380 mm
5096 10240 11840







Available as special accessories



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory

18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097

Bar Code: 4006825646962





18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory

Einhell Accessory

18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory















18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory

18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory

18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory

Q-Stick Scheibe Ø125 25tlg. Exzenterschleifer-Zubehör Item No.: 49491974 Bar Code: 4009314919745 Einhell Accessory

Battery-Running-Times

One Battery for All	sanding ¹
One Battery for All	(min.)
1.5 Ah	15
2.0 Ah	20
2.5 Ah	25
3.0 Ah	30
4.0 Ah	40
5.2 Ah	52
6.0 Ah	60
8.0 Ah	80

Test setup:

1) no-load