



## Als Sonderzubehör erhältlich



18V 2,0Ah Power X-Change  
Akku  
Art.-Nr.: 4511395  
EAN-Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Akku  
Art.-Nr.: 4511396  
EAN-Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Art.-Nr.: 4512042  
EAN-Code: 4006825613704  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Akku  
Art.-Nr.: 4511437  
EAN-Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
PXC-Ladegerät  
Art.-Nr.: 4512069  
EAN-Code: 4006825629729  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Art.-Nr.: 4512040  
EAN-Code: 4006825613681  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Akku  
Art.-Nr.: 4511341  
EAN-Code: 4006825590593  
Einhell Accessory

## Akku-Laufzeiten



Schrauben<sup>1</sup>  
(Stück)

Ein Akku Für alle Fälle

Akku Kapazität	Schrauben <sup>1</sup> (Stück)
1.5 Ah	230
2.0 Ah	305
2.5 Ah	380
3.0 Ah	460
4.0 Ah	610
5.2 Ah	770
6.0 Ah	920
8.0 Ah	1220

Testaufbau:

1) Schrauben - 6x60mm