



PROFESSIONAL



TP-AP 18/28 Li BL - Solo

Item No.: 4326310

Ident No.: 21032

Bar Code: 4006825644951

The Einhell TP-AP 18/28 Li BL - Solo cordless reciprocating saw is a member of the Power X-Change series . Each rechargeable battery in the system can be combined with any PXC device. The brushless motor offers more power and runs for longer, while the anti-vibration function ensures low vibration while working. The soft grip surfaces make the saw ergonomic to handle. The rotatable main handle ensures maximum flexibility. The adjustable soleplate enables optimal use of the blade, and tool-less blade changes keep things simple. A quality wood blade from KWB is included in the scope of delivery. This product comes without a battery or charger. We recommend at least 2.5 Ah.

OWER X-CHANGE

Features & Benefits

- A member of the Power X-Change family
- Brushless motor more power and prolonged operation
- Rotatable main handle for maximum flexibility
- Anti-vibration function ensures low vibration during operation
- Adjustable soleplate for optimum blade use
- Tool-less blade changes for rapid application
- Ergonomic handling thanks to soft grip surfaces
- For optimum results: rechargeable battery, 2.5 Ah or more
- Supplied without battery and charger (available separately)
- Incl. KWB quality blade (wood)

Technical Data

- Number of strokes 0 - 2500 min^-1

- Stroke height 28 mm - Cutting depth in wood 200 mm - Cutting depth in plastic 20 mm 12 mm - Cutting depth in steel - Toolless saw blade change yes



- Product weight 2.06 kg - Gross weight single packaging 2.71 kg

- Dimensions single packaging 445 x 175 x 110 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 11.85 ka

- Dimensions export carton 460 x 370 x 240 mm - Container quantity (20"/40"/40"HC) 2664 | 5484 | 6656





















Available as special accessories



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376



Sabersaw-bl. set 3pc W/M Batt All Purpose Saw Accessory Item No.: 49576105 Bar Code: 4009315761053 KWB by Einhell



18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578

Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory

Battery-Running-Times

One Battery for All	sawing ¹
	(pieces)
1.5 Ah	170
2.0 Ah	226
2.5 Ah	332
3.0 Ah	416
4.0 Ah	556
5.2 Ah	723
6.0 Ah	834
8.0 Ah	1112

For best performance select a battery with at least 2.5 Ah

Test setup:

1) softwood - round soft wood Ø 35 mm