



PROFESSIONAL



TP-BS 18/457 Li BL - Solo

Item No.: 4466270

Ident No.: 21011

Bar Code: 4006825663624

The Einhell cordless belt sander TP-BS 18/457 Li BL is a practical tool for evenly sanding large areas. The 18 V device is part of the combinable Power X-Change family. With its brushless motor, its 126x75 mm sanding surface, a max. sanding belt speed of 250 m/min and the continuous running lock, the cordless belt sander quickly processes even large areas. The sander is also provided with tool-free sanding belt installation & adjustment, an additional handle and a storage surface for stationary use. It has dust extraction and an extraction adapter. Delivery incl. dust collection box and 3x P80 sanding belts. Battery and charger sold separately.

OWER X-CHANGE

Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor more power and longer running time
- Electronic speed control for material- & usage-oriented work
- Tool-free sanding belt change thanks to locking lever
- Precise belt running through sanding belt adjustment
- Handle and additional handle with soft grip for optimal handling
- Integrated storage surface for stationary use
- Continuous running lock for comfortable working
- Integrated dust extraction and extraction adapter
- Dust box for dust-free workplace
- Incl. 3x sanding belt (P80)
- Supplied without battery and without charger (sold separately)

Technical Data

120 - 250 m/min - Belt speed 457 x 75 mm - Abrasive belt 126x75 mm - Grinding surface

Logistic Data

- Product weight (kg) 2.58 - Gross weight (kg) 3.33

355 x 170 x 200 mm - Dimensions single packaging

- Pieces per export carton 4 Pieces - Gross weight of export carton 15.5 kg

- Dimensions export carton 335 x 385 x 405 mm 2080 | 4048 | 4800 - Container quantity (20"/40"/40"HC)





















Available as special accessories



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509

Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 **Einhell Accessory**

18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory**



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory

Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729

Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 **Einhell Accessory**



2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



Schleifbandset, 75x457, 6tlg. Belt Sander Accessory Item No.: 4419815 Bar Code: 4006825665819 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory**



18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit Item No.: 4512114 Bar Code: 4006825656787 Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery Item No.: 4511600 Bar Code: 4006825665055 Einhell Accessory

Battery-Running-Times

	_
_	
_	•

One Battery for All	sanding¹ (min.)
1.5 Ah	11
2.0 Ah	15
2.5 Ah	18
3.0 Ah	22
4.0 Ah	30
5.2 Ah	38
6.0 Ah	44
8.0 Ah	59

Test setup:

1) no-load - Max. electronic speed