

Einhell

ACCESSORY

System Carrying Case

E-Case Tower

Item No.: 4540015

Ident No.: 21011

Bar Code: 4006825660609

The Einhell E-Case Tower is a member of the modular E-Case system from Einhell. It is suitable for storing and transporting tools and accessory. The locking system ensures the connection of stacked cases, this allows easy transport and storage. The case is made of polypropylene and is splash-proof, heat- and impact resistant due to the high-quality material. The stable construction allows a total payload of up to 120 kg. The large wheels, in parallel with the telescopic and extra-wide handle, provide a pleasant rolling experience - on any surface. A retractable ergonomic handle provides carrying comfort. Incl. in delivery: E-Case L with hand tool tray, 2x E-Case S with foam and compartments together with 3x inscribable stickers.

Features & Benefits

- Member of the modular E-Case-System from Einhell
- System box set to store/transport devices and its accessories
- Locking system for connecting stacked cases
- ensures easy storage and transport
- High-quality material polypropylene ensures heat resistance, stiffness and impact resistance
- robust and durable construction allows a payload of up to 120 kg
- easy transport thanks to telescopic, extra-wide handle
- 15 cm large wheels enable comfortable rolling on any surface
- Splash-proof design for transport during any weather condition
- 1x foldable + ergonomic handle for comfortable carrying, e.g. while pulling of the car trunk
- padlock applicable as anti-theft device
- including 3x inscribable sticker - to always know the contents
- E-Case L incl. 1x tray for hand tools
- E-Case S incl. foam inlay for scratch-free transport
- E-Case S incl. compartments for flexibility and tidiness
- including spacer clips to protect your hand of getting pinched

Technical Data


- | | |
|-------------------------------|--------------------|
| - Inner dimensions (E-Case S) | 415 x 280 x 95 mm |
| - Inner dimensions (E-Case L) | 415 x 273 x 320 mm |
| - Max. total payload | 120 kg |

Logistic Data

- | | |
|--|--------------------|
| - Product weight (kg) | 10.08 |
| - Gross weight (kg) | 11.32 |
| - Dimensions single packaging | 450 x 412 x 691 mm |
| - Pieces per export carton | 1 Pieces |
| - Gross weight of export carton | 11.52 kg |
| - Dimensions export carton | 450 x 412 x 691 mm |
| - Container quantities (20"/40"/40"HC) | 210 435 522 |



E-CASE-SYSTEM



The following Power X-Change devices fit into the E-Case L:

Artikeln.	Beschreibung		Bild
2093233	CE-CP 18/180 Li	Autotechnique Accessory	
4512064	Power X-Boostcharger 6A	Charger	
4512011	Power X-Charger 3A	Charger	
4512069	Power X-Twincharger 3A	Charger	
4512102	Power X-Quattrocharger 4A	Charger	
4512096	Power-X-Charger 18V	Charger	
4512103	Power X-Fastcharger 4A	Charger	
2093320	CE-CP 18/180 Li E	Cl. Polishing/Sanding Machine	
4260025	TC-SY 18/60 Li	Cl.Paint Spray Sys (Spray Gun)	
2070110	CE-AP 18 Li	Cordless Air Pump	
4326300	TE-AP 18 Li	Cordless All Purpose Saw	
4326290	TE-AP 18/26 Li	Cordless All Purpose Saw	
4326310	TE-AP 18/28 Li BL	Cordless All Purpose Saw	
4431140	AXXIO	Cordless Angle Grinder	

4431150	AXXIO 18/115 Q	Cordless Angle Grinder	
4431151	AXXIO 18/125 Q	Cordless Angle Grinder	
4431160	AXXIO 36/230 Q	Cordless Angle Grinder	
4431130	TC-AG 18/115 Li	Cordless Angle Grinder	
4431110	TE-AG 18/115 Li	Cordless Angle Grinder	
4431165	TE-AG 18/115 Q Li	Cordless Angle Grinder	
4431144	TE-AG 18/150 Li BL	Cordless Angle Grinder	
4466270	TP-BS 18/457 Li BL	Cordless Belt Sander	
4350630	TE-BJ 18 Li	Cordless Biscuit Jointer	
3408001	TE-CB 18/180 Li	Cordless Blower	
2071010	CE-CC 18 Li	Cordless Car Air Compressor	
2093301	CE-CB 18/254 Li	Cordless Car Polisher	
4501760	GE-LC 18/25 Li	Cordless Chain Saw	
4499940	GE-CS 18 Li	Cordless Chain Sharpener	
4331220	TE-CS 18/150 Li	Cordless Circular Saw	

4331207	TE-CS 18/165-1 Li	Cordless Circular Saw	
4331210	TE-CS 18/190 Li BL	Cordless Circular Saw	
4514160	TE-DA 18/760 Li	Cordless Drain Cleaner	
4513927	TC-CD 18/35 Li	Cordless Drill	
4513692	TE-CD 18 Li	Cordless Drill	
4513850	TE-CD 18 Li BL	Cordless Drill	
4513870	TE-CD 18 Li E	Cordless Drill	
4513925	TE-CD 18/40 Li	Cordless Drill	
4513997	TE-CD 18/40 Li BL	Cordless Drill	
4513887	TE-CD 18/50 Li BL	Cordless Drill	
4514210	TP-CD 18/60 Li BL	Cordless Drill	
4513990	TE-CD 18/45 3X-Li	Cordless Drill	
4259980	TE-DY 18 Li	Cordless Drywall Screwdriver	
3410370	GE-CG 18 Li	Cordless Grass- and Bush Shear	
3410313	GE-CG 18/100 Li	Cordless Grass- and Bush Shear	

3410310	GE-CG 18/100 Li T	Cordless Grass- and Bush Shear	
3410382	GC-CG 18/1 Li	Cordless Grass Shear	
4513960	TC-ID 18 Li	Cordless Hammer Drill	
4520500	TE-HA 18 Li	Cordless Hot Air Gun	
4522200	TE-CG 18 Li	Cordless Hot Glue Gun	
4513860	TE-CD 18 Li-i BL	Cordless Impact Drill	
4513926	TE-CD 18/48 Li-i	Cordless Impact Drill	
4513942	TE-CD 18/50 Li-i BL	Cordless Impact Drill	
4514205	TP-CD 18/60 Li- i BL	Cordless Impact Drill	
4510080	IMPAXXO 18/230	Cordless Impact Driver	
4510070	IMPAXXO 18/400	Cordless Impact Driver	
4510030	TE-CI 18 Li BL	Cordless Impact Driver	
4510034	TE-CI 18/1 Li	Cordless Impact Driver	
4510040	TE-CW 18 Li BL	Cordless Impact Driver	
4321209	TC-JS 18 Li	Cordless Jig Saw	

4321200	TE-JS 18 Li	Cordless Jig Saw	
4514130	TC-CL 18 Li H	Cordless Light	
4514115	TC-CL 18/1800 Li	Cordless Light	
4514110	TE-CL 18 Li	Cordless Light	
4514114	TE-CL 18/2000 LiAC	Cordless Light	
4514145	TE-CL 18/2500 LiAC	Cordless Light	
4331100	TE-CS 18/89 Li	Cordless Mini Circular Saw	
4465170	TC-MG 18 Li	Cordless Multifunctional Tool	
4465160	VARRITO	Cordless Multifunctional Tool	
4460713	TE-OS 18/1 Li	Cordless Multiple Sander	
4460708	TE-OS 18/150 Li	Cordless Multiple Sander	
4257790	TE-CN 18 Li	Cordless Nailer	
4460725	TC-OS 18/187 Li	Cordless Orbital Sander	
4460720	TE-OS 18/230 Li	Cordless Orbital Sander	
4258760	TE-MX 18 Li	Cordless Paint/Mortar Mixer	

4345400	TE-PL 18/82 Li	Cordless Planer	
3408220	GE-GS 18 Li	Cordless Pruning Saw	
3408300	GE-LS 18 Li	Cordless Pruning Shears	
3408017	TC-RA 18 Li BT	Cordless Radio	
3408015	TE-CR 18 Li	Cordless Radio	
4513900	HEROCCO	Cordless Rotary Hammer	
4513812	TE-HD 18 Li	Cordless Rotary Hammer	
4513970	TE-HD 18/12 Li	Cordless Rotary Hammer	
4462010	TE-RS 18 Li	Cordless Rotating Sander	
4350410	TP-RO 18 Set Li BL	Cordless Router / Palm Router	
4522250	TE-SG 18/28 Li	Cordless Sealing Gun	
4514150	TC-SR 18 Li BT	Cordless Speaker	
2347120	TE-VC 18 Li	Cordless Vacuum Cleaner	
4020460	PRESSITO	Hybrid-Compressor	
4600020	FORTEXXA 18/20 TH	Top-handled Cordless Chain Saw	

4514120	TC-CP 18 Li USB	USB Power Bank	
---------	-----------------	----------------	---

Suitable for E-Case S

(1x Power X-Charger 3A + 2x 3,0 Ah PXC Plus Battery)



AXXIO
Cordless Angle Grinder
Art.-No.: 4431140
EAN-Code: 4006825630558
Einhell Expert Plus



TE-AP 18 Li-Solo
Cordless All Purpose Saw
Art.-No.: 4326300
EAN-Code: 4006825601381
Einhell Expert Plus



TC-AG 18/115 Li-Solo
Cordless Angle Grinder
Art.-No.: 4431130
EAN-Code: 4006825628746
Einhell Classic



TE-AP 18/28 Li BL-Solo
Cordless All Purpose Saw
Art.-No.: 4326310
EAN-Code: 4006825644951
Einhell Expert Plus



TE-AG 18/150 Li BL-Solo
Cordless Angle Grinder
Art.-No.: 4431144
EAN-Code: 4006825644494
Einhell Expert Plus



AXXIO 18/115 Q
Cordless Angle Grinder
Art.-No.: 4431150
EAN-Code: 4006825642698
Einhell Expert Plus



TE-CD 18 Li-Solo
Cordless Drill
Art.-Nr.: 4513692
EAN-Code: 4006825658309
Einhell Expert Plus



TE-AG 18/115 Li-Solo
Cordless Angle Grinder
Art.-No.: 4431110
EAN-Code: 4006825602593
Einhell Expert Plus



TE-CD 18 Li Brushless for Kit
Cordless Drill
Art.-No.: 4513852
Einhell Expert Plus



AXXIO 18/125 Q
Cordless Angle Grinder
Art.-No.: 4431151
EAN-Code: 4006825650525
Einhell Expert Plus



TE-CD 18/2 Li for Kit
Cordless Drill
Art.-No.: 4513831
EAN-Code: 4006825622638
Einhell Expert Plus



TE-CD 18 Li E-Solo
Cordless Drill
Art.-No.: 4513870
EAN-Code: 4006825617740
Einhell Expert Plus



TE-CD 18/50 Li BL Solo
Cordless Drill
Art.-No.: 4513887
EAN-Code: 4006825644838
Einhell Expert Plus



TE-CD 18/40 Li-Solo
Cordless Drill
Art.-No.: 4513925
EAN-Code: 4006825635768
Einhell Expert



TE-CD 18 Li Brushless-Solo
Cordless Drill
EAN-Code: 4006825611366
Art.-Nr.: 4513850
Einhell Expert Plus



TC-CD 18/35 Li-Solo
Cordless Drill
Art.-No.: 4513927
EAN-Code: 4006825642452
Einhell Classic



TE-DY 18 Li-Solo
Cordless Drywall Screwdriver
Art.-No.: 4259980
EAN-Code: 4006825635607
Einhell Expert



TE-CG 18 Li-Solo
Cordless Hot Air Gun
Art.-No.: 4522200
EAN-Code: 4006825641202
Einhell Expert



TC-ID 18 Li-Solo
Cordless Hammer Drill
Art.-No.: 4513960
EAN-Code: 4006825647754
Einhell Classic



TE-CD 18 Li-i BL-Solo
Cordless Impact Drill
Art.-No.: 4513863
EAN-Code: 4006825618358
Einhell Expert Plus



TE-CD 18-2 Li-i-Solo
Cordless Impact Drill
Art.-No.: 4513802
EAN-Code: 4006825596779
Einhell Expert Plus



TE-CD 18/48 Li-i-Solo
Cordless Impact Drill
Art.-No.: 4513926
EAN-Code: 4006825635775
Einhell Expert



TE-CD 18 Li-i Brushless-Solo
Cordless Impact Drill
Art.-No.: 4513860
EAN-Code: 4006825612417
Einhell Expert Plus



TE-CI 18 Li Brushless-Solo
Cordless Impact Driver
Art.-No.: 4510030
EAN-Code: 4006825613971
Einhell Expert Plus



TE-CD 18/50 Li-i BL Solo
Cordless Impact Drill
Art.-No.: 4513942
EAN-Code: 4006825644265
Einhell Expert Plus



TE-CW 18 Li Brushless-Solo
Cordless Impact Driver
Art.-No.: 4510040
EAN-Code: 4006825616323
Einhell Expert Plus



TE-CI 18/1 Li-Solo
Cordless Impact Driver
Art.-No.: 4510034
EAN-Code: 4006825618907
Einhell Expert Plus



TE-JS 18 Li-Solo
Cordless Jig Saw
Art.-No.: 4321200
EAN-Code: 4006825601398
Einhell Expert Plus



TC-JS 18 Li-Solo
Cordless Jig Saw
Art.-No.: 4321209
EAN-Code: 4006825640052
Einhell Classic



TC-CL 18/1800 Li-Solo
Cordless Light
Art.-No.: 4514115
EAN-Code: 4006825644395
Einhell Classic



TE-CL 18 Li-Solo
Cordless Light
Art.-No.: 4514110
EAN-Code: 4006825600032
Einhell Expert Plus



TE-CL 18/2500 LiAC-Solo
Akku-Lampe
Art.-No.: 4514145
EAN-Code: 4006825649550
Einhell Expert



TE-CL 18 Li H-Solo
Cordless Light
Art.-No.: 4514130
EAN-Code: 4006825610451
Einhell Expert Plus



TC-MG 18 Li-Solo
Cordless Multifunctional Tool
Art.-No.: 4465170
EAN-Code: 4006825628593
Einhell Classic



VARRITO
Cordless Multifunctional Tool
Art.-No.: 4465160
EAN-Code: 4006825618648
Einhell Expert Plus



TE-OS 18/1 Li-Solo
Cordless Multiple Sander
Art.-No.: 4460713
EAN-Code: 4006825618181
Einhell Expert Plus



TE-OS 18/150 Li-Solo
Cordless Multiple Sander
Art.-No.: 4460708
EAN-Code: 4006825651218
Einhell Expert



TC-OS 18/187 Li Solo
Cordless Orbital Sander
Art.-No.: 4460725
EAN-Code: 4006825642735
Einhell Classic



GE-GS 18 Li-Solo
Cordless Pruning Saw
Art.-No.: 3408220
EAN-Code: 4006825618389
Einhell Expert Plus



GE-LS 18 Li-Solo
Cordless Pruning Shears
Art.-No.: 3408300
EAN-Code: 4006825652727
Einhell Expert



GE-CG 18 Li-Solo
Cordless Grass- and Bush Shear
Art.-No.: 3410370
EAN-Code: 4006825614213
Einhell Expert Plus



GE-CG 18/100 Li-Solo
Cordless Grass- and Bush Shear
Art.-No.: 3410313
EAN-Code: 4006825652710
Einhell Expert



GE-CG 18/1 Li-Solo
Cordless Grass Shear
Art.-No.: 3410382
EAN-Code: 4006825654875
Einhell Expert



TE-CR 18 Li-Solo
Cordless Radio
Art.-No.: 3408015
EAN-Code: 4006825609196
Einhell Expert Plus



TC-SR 18 Li BT-Solo
Cordless Speaker
Art.-No.: 4514150
EAN-Code: 4006825644531
Einhell Classic



HEROCCO
Cordless Rotary Hammer
Art.-No.: 4513900
EAN-Code: 4006825630343
Einhell Expert Plus



TE-RA 18 Li BT-Solo
Cordless Radio
Art.-No.: 3408017
EAN-Code: 4006825651492
Einhell Classic



TE-HD 18/12 Li-Solo
Cordless Rotary Hammer
Art.-No.: 4513970
EAN-Code: 4006825647778
Einhell Expert



TE-HD 18 Li-Solo
Cordless Rotary Hammer
Art.-No.: 4513812
EAN-Code: 4006825604054
Einhell Expert Plus



TE-HA 18 Li-Solo
Cordless Hot Air Gun
Art.-No.: 4520500
EAN-Code: 4006825647730
Einhell Expert



CE-CC 18 Li-Solo
Cordless Car Air Compressor
Art.-No.: 2071010
EAN-Code: 4006825658309
Einhell Car Expert



TE-CP 18 Li USB-Solo
USB Power Bank
Art.-No.: 4514120
EAN-Code: 4006825608878
Einhell Expert Plus