



Einhell

EXPERT

POWER X-CHANGE

Cordless Garden Pump

AQUINNA 18/28

Item No.: 4180440

Ident No.: 21012

Bar Code: 4006825668711

The Einhell cordless garden pump AQUINNA 18/28 is a powerful pump from the flexibly combinable Power X-Change family for cordless use. It has an ECO mode for maximum runtime and a BOOST mode for maximum power. In addition, the garden pump is equipped with a large water filler screw for filling and a drainage screw for frost protection. The slim and compact cordless pump is easily transported via the carrying handle and fixed to a permanent place of use with the help of the fastening holes. It is equipped with two robust metal threaded connections. Delivery does not include battery or charger.


Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Power level switch: ECO and BOOST mode
- Practical water filler screw for easy filling
- Frost protection thanks to easy draining via water drain plug
- Overload protection protects the motor from overheating damage
- High-quality, durable suction & pressure connection made of metal
- Easy transport and high mobility thanks to carrying handle
- Pump base with hole for secure, permanent mounting
- Robust mechanical seals for a long service life
- Supplied without battery and charger (sold separately)



Technical Data

- Max. delivery capacity 2800 L/h
- Max. suction height 6 m
- Max. delivery height / - pressure 25 m / 2.5 bar
- Max. water temperature 35 °C
- Connection suction side 33,3mm (R1 AG)
- Connection pressure side 33,3mm (G1 IG)



Logistic Data

- Product weight (kg) 2.55
- Gross weight (kg) 3.3
- Dimensions single packaging 476 x 185 x 250 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 11.2 kg
- Dimensions export carton 485 x 380 x 510 mm
- Container quantity (20"/40"/40"HC) 1152 | 2320 | 2900



Available as special accessories



Suction hose 4 m, plastics
Pump Accessory
Item No.: 4173635
Bar Code: 4006825549058
Einhell Accessory



Suction hose 7 m, plastics
Pump Accessory
Item No.: 4173645
Bar Code: 4006825549102
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



Adapter 33,3 mm (1") AG
Pump Accessory
Item No.: 4173761
Bar Code: 4006825662733
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



accessorysetpressureside (OFF)
Pump Accessory
Item No.: 4173762
Bar Code: 4006825663266
Einhell Accessory



accessorysetsuction&press(OFP)
Pump Accessory
Item No.: 4173763
Bar Code: 4006825663273
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Power X-Caravan Charger 3A
Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory





Saugschlauch 7 m Messing
Pump Accessory
Item No.: 4173640
Bar Code: 4006825549171
Einhell Accessory



Saugschlauch 4 m Messing
Pump Accessory
Item No.: 4173630
Bar Code: 4006825549133
Einhell Accessory

Battery-Running-Times

One Battery for All	 pumping water (boost) ¹ (min.)	 pumping water (eco) ² (min.)
	1.5 Ah	10
2.0 Ah	14	18
2.5 Ah	17	22
3.0 Ah	20	27
4.0 Ah	28	36
5.2 Ah	36	47
6.0 Ah	40	54
8.0 Ah	56	72

Test setup:

1) BOOST

2) ECO