



Cordless Lawn Mower

RASARRO 18/33 - Solo

Item No.: 3413267 Ident No.: 21012

Bar Code: 4006825671360

The Einhell cordless lawn mower RASARRO 18/33-Solo is a powerful device for wireless garden maintenance. It is part of the combinable Power X-Change family. The device is powered by a PurePOWER brushless motor for more power and longer runtime. After online registration, there is a 10year warranty on the motor. The 5-stage central cutting height adjustment (25-65 mm) allows adjustment of the cutting height. The 30-litre collection basket is fitted with a fill level indicator. The mower has a cutting width of 33 cm and has a height-adjustable, foldable guide bar. The cordless lawn mower is recommended for areas up to 200 m². Delivery does not include battery or charger.

OWER X-CHANGE

Features & Benefits

- Member of the Power X-Change family, 1 x 18 V battery required
- Brushless motor more power and longer running time
- 5-level central cutting height adjustment (25 65 mm)
- Foldable guide handle for space-saving storage
- Continuous height-adjustable guide rail
- Integrated carrying handle for easy transport
- 30 I grass catch box with fill level indicator
- Lawn-protecting wheels with large tread area
- Recommended for lawn areas up to 200 m²
- Recommended for optimum results: 2.5 Ah battery and larger
- Supplied without battery and without charger (sold separately)

Technical Data

| - | Idle | speed |
|---|------|-------|
|---|------|-------|

- Cutting width
- Cutting height adjustment
- Capacity of catching device
- Wheel diameter front
- Wheel diameter rear

Logistic Data

| - Gross weight (kg) |
|-------------------------------|
| - Product weight (kg) |
| - Dimensions single packaging |
| - Pieces per export carton |
| - Gross weight export carton |

- Dimensions export carton
- Container quantity (20"/40"/40"HC)

3400 min^-1 33 cm 5 | 25-65 mm | central 301 150 mm 180 mm





ADIUSTMENT

2.5 A

Available as special accessories



Spare Blade GE-CM 33 Li+36/34 Lawn Mower Accessory Item No.: 3405452 Bar Code: 4006825610611 Einhell Accessory



Einhell Accessory 18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704

Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory

Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



. .

18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

Battery-Running-Times

| lawn mowing ¹ |
|--------------------------|
| (m²) |
| 50 |
| 100 |
| 140 |
| 180 |
| 250 |
| 300 |
| 350 |
| 500 |
| |

For best performance select a battery with at least 2.5 Ah

Test setup:

1) lawn