



Einhell

EXPERT

POWER X-CHANGE

Cordless Lawn Mower

RASARRO 36/37 - Solo

Item No.: 3413245

Ident No.: 21012

Bar Code: 4006825671353

The Einhell cordless lawn mower RASARRO 36/37-Solo is a powerful device for wireless home garden maintenance. The mower is part of the flexibly combinable Power X-Change family and is powered by two 18 V batteries using 36 V twin pack technology. The six-stage central cutting height adjustment (25–75 mm) allows individual adjustment of the cutting height. The 45-litre collection basket is fitted with a fill level indicator. The mower has a cutting width of 37 cm and has a height-adjustable, foldable guide bar. The cordless lawn mower is recommended for areas up to 400 m². Delivery does not include battery or charger. These are available separately.

Features & Benefits



- Member of the Power X-Change family, 2 x 18 V battery required
- TWIN-PACK technology: 2x18V Power X-Change batteries - more power
- 6-level central cutting height adjustment (25 - 75 mm)
- 45l grass collection bag with filling indicator
- Fatigue-free operation thanks to ergonomically shaped handle
- Integrated carrying handle for easy transport
- Space saving storage thanks to foldable long handle
- Individually height-adjustable guide rail
- Sturdy and lightweight aluminium guide rail
- Integrated lawn comb enables close-to-the-edge mowing
- Highwheeler with large wheels that are gentle on the lawn
- Recommended for lawn areas up to 400 m²
- Recommended for optimum results: 2.5 Ah batteries and higher
- Supplied without battery and charger (sold separately)

Technical Data

- Idle speed	3400 min ⁻¹
- Cutting width	37 cm
- Cutting height adjustment	6 25-75 mm central
- Capacity of catching device	45 L
- Wheel diameter front	150 mm
- Wheel diameter rear	220 mm

Logistic Data

- Gross weight (kg)	17.6
- Product weight (kg)	13.45
- Dimensions single packaging	850 x 470 x 370 mm
- Pieces per export carton	1 Pieces
- Gross weight export carton	17 kg
- Dimensions export carton	835 x 465 x 370 mm
- Container quantity (20"/40"/40"HC)	195 398 465



Available as special accessories



Spare Blade GE-CM 36/37+38
Lawn Mower Accessory
Item No.: 3405486
Bar Code: 4006825635843
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times



lawn mowing¹
(m²)

One Battery for All

1.5 Ah	200
2.0 Ah	250
2.5 Ah	290
3.0 Ah	400
4.0 Ah	450
5.2 Ah	650
6.0 Ah	800
8.0 Ah	900

For best performance select a battery with at least 2.5 Ah

Test setup:

1) lawn