







Cordless Scarifier / Aerator

GC-SCA 18/280 BL

Item No.: 3420605

Ident No.: 21013

Bar Code: 4006825672312

The Einhell cordless scarifier GC-SCA 18/280 BL offers wireless freedom and is recommended for areas up to 200 m². The batteries, chargers and system devices of the PXC series can be combined with each other. The tool is powered by the Einhell PurePOWER brushless motor for more power and longer running time. After online registration, the motor comes with a 10-year warranty. It can optionally be extended to a 3-in-1 combi unit with a basket. The ball-bearing roller has 12 rotating knives. A fan roller is included in delivery. The 3-stage working depth adjustment with transport position as well as the foldable and height-adjustable guide beam allow comfortable working. Delivery without battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Brushless motor more power and longer running time
- PurePOWER Brushless 10 year motor warranty after registration
- Ball-bearing scarifier drum with 12 rotating knives
- Including fan roller with 24 claws made of stainless steel
- 3-stage working depth adjustment with transport position
- Foldable and height-adjustable guide bar
- Grass-friendly, large-area wheels
- Impact-resistant plastic housing
- Optionally expandable to the 3in1 combi device (basket)
- Recommended for lawns up to 200 m²
- Supplied without battery or charger (sold separately)

Technical Data

- Working width 280 mm 12 Pieces - Number of knives - Number of spikes 24 Pieces - Wheel diameter front 150 mm - Wheel diameter rear 100 mm

Logistic Data

- Tool weight 6.8 kg - Gross Weight 9.9 kg

- Dimensions single packaging 510 x 510 x 245 mm

- Pieces per export carton 1 Pieces - Gross weight of export carton 9.2 kg

518 x 500 x 245 mm - Dimensions export carton - Container quantity (20"/40"/40"HC) 396 | 828 | 920





















Available as special accessories



18V 4-6Ah Multi-Ah PXC Plus

Battery Item No.: 4511502

Bar Code: 4006825644210

Einhell Accessory



18V 2,0Ah Power X-Change

Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042

Bar Code: 4006825613704 **Einhell Accessory**

18V 2,5Ah Power X-Change Battery Item No.: 4511516

Bar Code: 4006825650518

Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512108 Bar Code: 4006825652376 Einhell Accessory



18V Battery Charger 3,0A - PXC

Charger Item No.: 4514095 Bar Code: 4006825655292

Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766

Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit Item No.: 4512114 Bar Code: 4006825656787

Einhell Accessory



Catch Bag GC-SC 18/28 Li Scarifier Accessory Item No.: 3405940 Bar Code: 4006825658798

Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1

Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory



Power X-Boostcharger 6A

Charger Item No.: 4512064

Bar Code: 4006825629019 Einhell Accessory



18V 3,0 Ah Power-X-Change 2

Battery Item No.: 4511341

Bar Code: 4006825590593

Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143

Bar Code: 4006825667653

Einhell Accessory



18V 3,0Ah Power X-Change Plus

Battery

Item No.: 4511501

Bar Code: 4006825644197

Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097

Bar Code: 4006825646962

Einhell Accessory

18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396

Bar Code: 4006825610376

Einhell Accessory



2x2 Power X-Quattrocharger 4A

Charger Item No.: 4512102

Bar Code: 4006825649536

Einhell Accessory



Power X-Fastcharger 4A

Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory

Power X-Twincharger 3A

Charger


Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



Power X-Car Charger 3A

Charger Item No.: 4512113 Bar Code: 4006825655377

Einhell Accessory



Bar Code: 4006825656695 Einhell Accessory

Areator roller GC-SC 18/28 Li

Scarifier Accessory Item No.: 3405941 Bar Code: 4006825658804

Einhell Accessory

Scarifierroller GC-SC 18/28 Li

Scarifier Accessory Item No.: 3405942

Bar Code: 4006825658811

Einhell Accessory

18V 4,0Ah Power-X-Change Plus

Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory

Power X-Caravan Charger 3A

Charger Item No.: 4512136 Bar Code: 4006825664010 Einhell Accessory

18V 5-8Ah Multi-Ah PXC Plus Battery Item No.: 4511600

Bar Code: 4006825665055

Einhell Accessory

18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437

Bar Code: 4006825616606 Einhell Accessory

Battery-Running-Times

_	
_	$\sim M$
•	.4/14

One Battery for All	scarifying¹ (m²)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240
8.0 Ah	320

For best performance select a battery with at least 2.5 Ah

Test setup:

1) dethatch