







#### **TE-MS 18/210 Li-Solo**

Item No.: 4300890

Ident No.: 21032

Bar Code: 4006825628074

OWER X-CHANGE

The Einhell TE-MS 18/210 Li - Solo cordless crosscut saw is ideal for the home & workshed. Being a member of the Power X-Change family means there are no interfering cables & the range of operation is literally unlimited. Compact with carry handle, it offers plenty of features to keep the workplace clean. These include the turntable with precise angle setting, the tiltable saw head for exact miter cuts, cutting line laser, LED & clamp for securing the workpiece. The X-Tend supports can be adjusted without tools. Integrated limit stop for repeat cutting. The carbide-tipped precision saw blade was developed for cordless saws. The sawdust bag/chip extraction system keep the workplace/air clean. The batteries/charger are available separately.

#### Features & Benefits

- Member of the Power X-Change family
- Boundless reach of action, no annoying cable, nothing to wind
- Compact, light construction and handle for easy transportation
- Turntable with precise angle setting for angular cuts
- Saw head tilts to the left and right for miter cutting
- X-Tend work supports with ergonomic singlehand operation facility
- High-grade precision saw blade, developed for cordless mitre saws
- Laser and LED for easy and safe use
- Clamping device for holding the workpiece securely in position
- Includes sawdust bag to keep the workplace clean
- Recommendation for best results: PXC 2.5 Ah battery or higher

### **Technical Data**

- Product weight (kg) 7.8 3000 min^-1 - No-load speed (idle speed) - Saw blade Ø210 x Ø30 mm - Number of saw teeth 40 Pieces 45° - 0° - Mitre cut 47° - 47° - Swivelling range - Cutting capacity 90° x 90° 120 x 60 mm - Cutting capacity 90° x 45° 83 x 60 mm - Cutting capacity 45° x 90° 120 x 34 mm - Cutting capacity 45° x 45° 80 x 34 mm - Diameter of suction adapter 36 mm



- Gross weight (kg) - Dimensions single packaging

- Pieces per export carton

- Gross weight of export carton - Dimensions export carton

- Container quantity (20"/40"/40"HC)

9.5

540 x 361 x 305 mm

1 Pieces 9.5 kg

540 x 355 x 300 mm

448 | 924 | 1040





















## Available as special accessories



E-Stand Stationary Saw Accessory Item No.: 4310620 Bar Code: 4006825584974 Einhell Accessory



MSS 1610 Stationary Saw Accessory Item No.: 4310615 Bar Code: 4006825637496 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210

**Einhell Accessory** 



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory



18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



MSS 1608 Stationary Saw Accessory Item No.: 4310614 Bar Code: 4006825660050 Einhell Accessory



Sbl D 210x30x1,8 T40 Stationary Saw Accessory Item No.: 49587852 Bar Code: 4009315878522 Einhell Accessory



Sbl D 210x30x2,4 T48 Stationary Saw Accessory Item No.: 49587861 Bar Code: 4009315878614 Einhell Accessory



Sbl D 210x30x1,8 T64 Stationary Saw Accessory Item No.: 49587862 Bar Code: 4009315878621 Einhell Accessory



Sbl Set D 210x30x2,5 T24/42/60 Stationary Saw Accessory Item No.: 49587805 Bar Code: 4009315878058 Einhell Accessory



Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory

Einhell Accessory



Sbl D 210x30x2,6 T24 Stationary Saw Accessory Item No.: 4502067 Bar Code: 4006825667790 Einhell Accessory



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606



18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory

# **Battery-Running-Times**

One Battery for All	sawing <sup>1</sup>
	(pieces)
1.5 Ah	72
2.0 Ah	103
2.5 Ah	120
3.0 Ah	154
4.0 Ah	190
5.2 Ah	250
6.0 Ah	304
8.0 Ah	400

For best performance select a battery with at least 2.5 Ah

1) softwood - scantling 60x60 mm