



Einhell

PROFESSIONAL



Cordless Jig Saw

TP-JS 18/135 Li BL - Solo

Item No.: 4321260

Ident No.: 21011

Bar Code: 4006825666618

The Einhell Professional cordless jigsaw TP-JS 18/135 Li BL is part of the powerful, combinable Power X-Change family. The tool is driven by a PurePOWER brushless motor for enhanced power and longer runtimes. Once you register online, the brushless motor has a 10-year warranty. Its very smooth operation allows precise cutting, while the pendulum stroke can be enabled for quick cuts. The jigsaw is capable of cutting depths of up to 135 mm in wood and 10 mm in steel as well as oblique cuts of up to 45°. It features speed electronics, a cutting line indicator, tool-free saw blade holder, splinter guard and a soft-start function. Comes with 1x jigsaw blade for wood, but without battery or charger.

Features & Benefits

- Part of the Power X-Change family, 1x 18 V battery required
- Brushless motor – more power and longer running time
- PurePOWER brushless – 10-year motor warranty with registration
- Very smooth operation for precise cutting
- Switchable pendulum stroke for quick cuts
- Speed electronics for optimal tool control
- Tool-free blade holder
- With dust blower function for optimal visibility
- LED light to illuminate the area being cut
- Cutting line indicator for precise cuts
- Sturdy aluminium base plate for lower vibrations
- The integrated plastic glide insert protects delicate workpieces.
- Rip fence for precise, straight cuts
- Incl. chip tear protection for tear-free cuts
- Soft-start for high levels of safety and protection of the motor
- Incl. 1x jigsaw blades for wood
- Comes without battery or charger (sold separately)



Technical Data

- | | |
|-----------------------------|----------------------------|
| - No-load speed | 0 - 3500 min ⁻¹ |
| - Stroke height | 26 mm |
| - Cutting depth in wood | 135 mm |
| - Cutting depth in plastic | 20 mm |
| - Cutting depth in steel | 10 mm |
| - Max. bevel cuts | 45 ° |
| - Toolless saw blade change | yes |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight | 2.19 kg |
| - Gross weight single packaging | 3.08 kg |
| - Dimensions single packaging | 235 x 97 x 315 mm |
| - Pieces per export carton | 5 Pieces |
| - Gross weight export carton | 16 kg |
| - Container quantity (20"/40"/40"HC) | 3325 6885 8075 |

18 V



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery
Item No.: 4511489
Bar Code: 4006825638578



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Stich-Sägeblatt Box 10-tlg. T Stichsäge-Zubehör
Item No.: 49617350
Bar Code: 4009316173503
Einhell Accessory



St-Sägebl.Set 4tg Ho/Met Akku Stichsäge-Zubehör
Item No.: 49625427
Bar Code: 4009316254271
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

Battery-Running-Times



sawing¹
(m)

One Battery for All

1.5 Ah	11
2.0 Ah	14
2.5 Ah	18
3.0 Ah	21
4.0 Ah	29
5.2 Ah	37
6.0 Ah	43
8.0 Ah	57

Test setup:

1) wood - chipboard 19 mm