



Cordless Impact Drill

TE-CD 18/48 Li-i (2x2,0Ah)

ltem No.: 4513935

Ident No.: 21043

Bar Code: 4006825643930

The Einhell TE-CD 18/48 Li-i (2x2.0Ah) cordless impact drill driver is a high-power member of the PXC family. Two 2.0 Ah rechargeable batteries from the PXC series and a charger are included with the product. The rechargeable batteries with zero self-discharge are completely interchangeable. The inclusive impact drilling function means it is designed for universal work, and the 2-speed gearing is suitable for powerful drilling and screwdriving. Electronic speed control ensures that the tool can be adjusted to the particular material and application. For exceptionally easy handling it has an ergonomic design and soft grip. For an optimum view of the work area, an LED light is included. Supplied in a practical transport and storage case.

OWER X-CHANGE

Features & Benefits

- A member of the Power X-Change family
- Impact drilling function for universal operation included
- 2-speed gearing for powerful drilling and screwing
- Speed electronics for material and application suitable working
- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and Softgrip
- Supplied with two 2,0 Ah battery and charger
- Delivered in a practical case

Technical Data

- Accumulator

- Charging time
- Number of gears
- Idle speed (gear 1)
- Idle speed (gear 2)
- Max. torque hard
- Number of torque steps
- Drill chuck
- Impact rate (gear 1)
- Impact rate (gear 2)
- Number of accumulators

Logistic Data

- Product weight
- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

18 V | 2000 mAh | Li-Ion 40min 2 0-400 min^-1 0-1500 min^-1 48 Nm 21+1+1 settings 13 mm | single sleeve 0-6400 min^-1 0-24000 min^-1 2 Pieces

1.5 kg 3.67 kg 340 x 100 x 350 mm 4 Pieces 16 kg 430 x 365 x 355 mm 2008 | 4160 | 4880









Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery Item No.: 4511502 Bar Code: 4006825644210

4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory**



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 **Einhell Accessory**



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512108 Bar Code: 4006825652376 **Einhell Accessory**



18V 3,0 Ah Power-X-Change 1 Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

2x 4,0Ah & Twincharger Kit 1

PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766



5,2Ah & 4A Fastcharger PXC-Starter-Kit Item No.: 4512114 Bar Code: 4006825656787 **Einhell Accessory**

Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB A1 Battery Item No.: 4511489 Bar Code: 4006825638578

Power X-Caravan Charger 3A Charger Item No.: 4512136 Bar Code: 4006825664010 Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653 Einhell Accessory

5,2 Ah Power X-Change Plus



Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory

18V 3Ah PXC Plus Twinpack Battery Item No.: 4511631 Bar Code: 4006825673692 **Einhell Accessory**

2,0 Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 **Einhell Accessory**



















18V 5-8Ah Multi-Ah PXC Plus **Einhell Accessory**





PXC Battery Protector PXC-Battery Accessory Item No.: 4140151 Bar Code: 4006825670844 Einhell Accessory

18V 4Ah PXC Plus Twinpack Battery Item No.: 4511629 Bar Code: 4006825673685 Einhell Accessory





18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory

18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 **Einhell Accessory**

18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory

18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory**

Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 **Einhell Accessory**

Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory

PXC Battery Mounting Gadget PXC-Battery Accessory Item No.: 4514155 Bar Code: 4006825658774 **Einhell Accessory**

3,0 Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 **Einhell Accessory**

Battery Item No.: 4511600 Bar Code: 4006825665055



GS mark belongs to the product itself only, excluded accessory Page 2

Battery-Running-Times

One Battery for All	screwing ¹
	(pieces)
1.5 Ah	230
2.0 Ah	310
2.5 Ah	380
3.0 Ah	460
4.0 Ah	620
5.2 Ah	780
6.0 Ah	910
8.0 Ah	1240

Test setup:

1) wood - 6x60 mm