MAINTENANCE

- · Keep the ventilation vents of the sander clean at all times, if possible, prevent foreign matter from entering the vents.
- After each use, blow air through the sander housing to ensure it is free from all dust particles which may build up. Build up of dust particles may cause the drill to overheat and fail.
- If the enclosure of the drill requires cleaning, do not use solvents but a moist soft cloth only. Never let any liquid get inside the drill; never immerse any part of the drill into a liquid.

Replacing the Hook & Loop Backing Pad

After considerable use, the hook and loop backing pad surface will become worn, and must be replaced when it no longer offers a firm grip. The replacement backing pad can be ordered through the Special Orders Desk at any Bunnings store

- 1. To replace, remove the four philips head screws by rotating anti-clockwise.
- 2. Place new backing pad on the tool and retighten the four philips head screws by rotating clockwise
- Note: Ozito Industries will not be responsible for any damage or injuries caused by the repair of the tool by an unauthorised person or by mishandling

DESCRIPTION OF SYMBOLS



Danger! Read the operating instructions to reduce the risk of



Double insulated / Protection class II



damage to hearing. Caution! Wear a breathing mask. Dust which is injurious to

Caution! Wear ear-muffs. The impact of noise can cause

health can be generated when working on wood and other

working or splinters, chips and dust emitted by the device can



materials. Never use the device to work on any materials containing asbestos! Caution! Wear safety goggles. Sparks generated during

SERVICE INFORMATION

cause loss of sight

Please note that the following parts of this product are subject to normal or natural wear and that the following parts are therefore also required for use as consumables.

Category	Example
Wear parts*	Grinding/sanding plate
Consumables*	Grinding/sanding paper
Missing parts	

^{*} Not necessarily included in the scope of delivery

TROUBLE SHOOTING

Sparking visible through the housing air vents

A small amount of sparking may be visible through the housing vents. This is normal and does not indicate a problem

Excessive sparking visible through the housing air vents and/or the drill failing to operate

May indicate the carbon brushes have worn out and need to be replaced. Carbon brushes should only be replaced by a qualified electrician or power tool repairer.

Sanding bases are not aligning correctly

The mounting plate at the base of the tool may need to be rotated slightly so that the holes align correctly. Ensure there are no aligning pins stuck into the base of the tool.

For the triangular and rectangular sanding bases, also check that there are 4 aligning pins positioned correctly in the top of the sanding pad.

Sandpaper Selection

Selecting the correct grit of sandpaper is an important step in achieving optimum results. Coarse grit will remove the most material. Finer grit will produce a smoother finish. The condition of the workpiece will determine the grit of the sandpaper to be used. The higher the grit number, the finer the grade of sandpaper.

If the surface is rough, start with a coarse grit and sand until the surface is uniform. Medium grit may then be used to remove scratches left by the coarser arit. Finer arit is then used to finish the surface. Always continue sanding with each grade of sandpaper until the surface is uniform.

WATERIAL		ALL KOLKIALE OKLI	
		Coarse Sanding	Fine Sanding
Paintwor	k	180	400
Wood:	Softwood	60	240

Note: If intermediate sanding is required, choose a grit rating between coarse and fine. The above table is intended as a guide only. To ensure a satisfactory result. a small, inconspicuous area should first be tested to ensure the grit of sandpaper chosen is suitable for the desired finish.

320

Sanding Tips

Never force the sander. The weight of the sander supplies adequate pressure, allowing the sandpaper to do the work. Applying additional pressure will slow the motor, rapidly wear the sandpaper, and greatly reduce the sander speed. This will slow the removal rate and produce an inferior quality surface. **CAUTION**: Excessive pressure will overload the motor, causing possible damage

to the sander by overheating the motor; or damage to the workpiece. Be sure to check your workpiece often. The sander is capable of removing

material rapidly, especially with coarse paper.

The orbital action of your sander allows you to sand with the grain, or at any angle across it for most sanding jobs. In the final stages a better finish will be achieved by sanding with the grain

Do not sand on one spot for too long. The sander's rapid action may remove too much material, creating an uneven surface.

SPARE PARTS

Spare parts can be ordered from the Special Orders Desk at your local Bunnings Warehouse or Homebase

For further information, or any parts visit www.ozito-diy.co.uk or contact Ozito Customer Service: Great Britain: 0151 294 4488

Ireland: 1850 882711

E-mail: info@ozito-diy.co.uk

Sound and vibration values were measured in accordance with EN 60745.

L₂₂ sound pressure level: 79.0 dB uncertainty: 3 dB sound power level: 90.0 dB 3 dB uncertainty:

Wear ear-muffs.

Total vibration values (vector sum of three directions) determined in

Vibration emission value $a_h = 13.7 \text{ m/s}^2$ K uncertainty = 1.5 m/s²

electric power tools.

- · Only use appliances which are in perfect working order.

- Have the appliance serviced whenever necessary.
- Wear protective gloves

The impact of noise can cause damage to hearing.

accordance with EN 60745.

Additional information for electric power tools

The specified vibration value was established in accordance with a standardized testing method. It may change according to how the electric equipment is used and may exceed the specified value in exceptional The specified vibration value can be used to compare the equipment with other

The specified vibration value can be used for initial assessment of a harmful

Keep the noise emissions and vibrations to a minimum.

- Service and clean the appliance regularly.
- Adapt your working style to suit the appliance
- Do not overload the appliance.
- Switch the appliance off when it is not in use.

SOUND & VIBRATION

For EU countries only

Never place any electric power tools in your household refuse. To comply with European Directive 2012/19/EC concerning old electric and electronic equipment and its implementation in national laws, old

Recycling alternative to the return request:

As an alternative to returning the equipment to the manufacturer, the owner of the electrical equipment must make sure that the equipment is properly disposed of if he no longer wants to keep the equipment. The old equipment can be returned to a suitable collection point that will dispose of the equipment in accordance with the national recycling and waste disposal regulations. This does not apply to any accessories or aids without electrical components supplied with the old equipment.


electric power tools have to be separated from other waste and disposed


of in an environment-friendly fashion, e.g. by taking to a recycling depot.

The reprinting or reproduction by any other means, in whole or in part, of documentation and papers accompanying products is permitted only with the express consent of the iSC GmbH.

Subject to technical changes

DECLARATION OF CONFORMITY





Read the whole manual carefully and make sure you know how to switch the tool off in an emergency

Save these instructions and other documents supplied with this tool for future reference Before you connect the equipment to the mains supply make sure that the data on the rating plate are

nis tool is double insulated therefore no earth wire is required

If the supply cord is damaged, it must be replaced by an electrician or a power tool repairer in order to avoi

Note: Double insulation does not take the place of normal safety precautions when operating this tool. The insulation system is for added protection against injury resulting from a possible electrical insulation failure

Using an Extension Lead

Always use an approved extension lead suitable for the power input of this tool. Before use, inspect the extension lead for signs of damage, wear and ageing. Replace the extension lead if damaged or defective When using an extension lead on a reel, always unwind the lead completely. Use of an extension lead not suitable for the power input of the tool or which is damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk of fire and electronic damaged or defective may result in a risk o

GENERAL POWER TOOL SAFETY WARNINGS



provided with this power tool." Failure to follow the warnings and instructions may result in electric Save all warnings and instructions for future reference. The term "power tool" in the warnings refers o your mains-operated (corded) power tool or battery-operated (cordless) power tool.

- Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes. c. Keep children and bystanders away while operating a power tool. Distractions can cause you to
- 2. Electrical safety a. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any
- adapter plugs with earthed (grounded) power tools. Unmodified plugs and reduce risk of electric shock. b. Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and
- refrigerators. There is an increased risk of electric shock if your body is earthed or grounded. c. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock
- d. Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e. When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f. If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
- a. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A b. Use personal protective equipment. Always wear eye protection. Protective equipment such as dust
- mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries. Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts If devices are provided for the connection of dust extraction and collection facilities, ensure

. Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left

Do not overreach. Keep proper footing and balance at all times. This enables better control of the

- these are connected and properly used. Use of dust collection can reduce dust-related hazards.

 Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.
- a. Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be
- strolled with the switch is dangerous and must be repaired Disconnect the plug from the power source and/or remove the battery pack, if detachable, from

power tool in unexpected situations

- the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally. Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands
- Maintain power tools and accessories. Check for misalignment or binding of moving parts breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power
- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for tions different from those intended could result in a hazardous situation.

parts. This will ensure that the safety of the power tool is maintained

Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations. Have your power tool serviced by a qualified repair person using only identical replacement

MULTI SANDER SAFETY WARNINGS

Additional saftey instructions for sanders

- This tool may be only be used for dry grinding/sanding operations.
- · Always guide the power cable away from the back of the tool.
- Use of the tool on materials containing asbestos is prohibited · Always remove the plug from the power supply socket before carrying out any work on the machine (cleaning the sander, changing the sandpaper, etc).
- Always disconnect the machine by removing the plug from the socket, not by pulling on the power cable.
- · Keep your workplace clean and well illuminated.
- Make sure that the workpiece is sufficiently secured so that it cannot slip. Keep children away. • For your own sake, keep the machine clean at all times and check it for signs of
- damege each time after using it Make sure that the switch is set to OFF before you insert the plug into the power
- supply socket. • Make sure of your footing, particularly when working on ladders and platforms.
- Harmful or toxic dust can be produced when working on wood or metal. Touching or inhaling this dust can be harmful for the operator and other persons nearby.

- · Hold the equipment by the insulated handles because the grinding/sanding belt may strike the equipment's own power cable. Damaging a live cable may make the matal parts of the equipment live and cause an electric shock. To protect your health, always wear safety goggles and a dust mask during sanding/
- frinding work! • If you discover any damage to the machine, use the exploded diagram and the spare
- parts list to determine which parts need to be ordered from Customer Service. Important! Wear safety googles and a dust mark.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance

Do not lose these safety instructions


No Load Speed: 7 000-12 000/mir Paper Fitment: Hook & Loop Paper Size: 145x100mm (Triangular 125mm (Circular)


ORIGINAL INSTRUCTIONS

145x100mm (Triangula 123mm (Circular) 183x92mm (1/3 Sheet

Oscillating Speed: 14.000-24.000/min Oscillating Circuit: 0.8mm Protection Class:

Tool Weight:







MSK-001U

WARRANTY

ozíto

All of our products undergo strict quality checks to ensure that they reach you in perfect condition. In the unlikely event that your device develops a fault, please contact our service department at the address shown on this guarantee card. You can also contact us by telephone using the customer service number shown. Please note the following terms under which quarantee claims can be made:

YEAR REPLACEMENT WARRANTY

- . These warranty terms regulate additional warranty services, which the manufacturer mentioned below promises to buyers of its new products in addition to their statutory guarantee claims are not affected by this guarantee. Our guarantee is free of charge to you.
- 2. The warranty services only covers defects due to material or manufacturing faults on a product which you have bought from the manufacturer mentioned below are limited to either the rectification of said defects on the product or the replacement of the product, whichever we

Please note that our devices are not designed for use in commercial, trade or professional applications. A guarantee contract will not be created if the device has been used by commercial, trade or industrial business or has been exposed to similar stresses during the guarantee period.

- 3. The following are not covered by our guarantee:
- Damage to the device caused by a failure to follow the assembly instructions or due to incorrect installation, a failure to follow the operating instructions (for example connecting it to an incorrect mains voltage or current type) or a failure to follow the maintenance and safety instructions or by exposing the device to abnormal environmental conditions or by lack
- of care and maintenance. - Damage to the device caused by abuse or incorrect use (for example overloading the device or the use or unapproved tools or accessories). ingress of foreign bodies into the device (such as sand, stones or dust. transport damage), the use of force or damage caused by external forces (for example by dropping it).
- Damage to the device or parts of the device caused by normal or natural wear or tear or by normal use of the device

4. Your Product is guaranteed for a period of 36 months from the original date of purchase and is intended for DIY (Do It Yourself) use only. Warranty excludes consumable parts. Guarantee claims should be submitted before the end of the guarantee period within two weeks of the defect being noticed. No guarantee claims will be accepted after the end of the guarantee period. The original guarantee period remains applicable to the device even if repairs are carried out or parts are replaced. In such cases, the work performed or parts fitted will not result in an extension of the guarantee period, and no new guarantee will become active for the work

IN ORDER TO MAKE A CLAIM UNDER THIS WARRANTY YOU MUST RETURN THE PRODUCT TO THE PLACE OF PURCHASE WITH YOUR REGISTER RECEIPT


Please refer to the restrictions of this warranty concerning wearing parts, consumables and missing parts as set out in the service information in these operating instructions.

Ozito-diy.co.uk











performed or parts fitted. This also applies if an on-site service is used.

CUSTOMER SERVICE HELPLINE GB: 0151 294 4488 IRL: 1850 882711


OZITO UK Champion's Business Park, Unit 10, 1st Floor, Arrowe Brook Road, Upton, Wirral, Merseyside, CH49 0AB

MULTI SANDER

1 Variable Speed Dial

4 Sure Grip Handle 2 Hook & Loop Sanding Pad 5 Dust Canister


3 On/Off Switch



ACCESSORIES

- 6 Random Orbital Sanding Base 9 Sheet Sanding Paper x 1
- 7 Random Orbital Sanding Paper x 1 (120Grit)
- 8 Sheet Sanding Base

10 Detail Sanding Base 11 Detail Sanding Paper x 1 (80Grit)



ONLINE MANUAL

Scan this QR Code with your mobile device to take you to the online manual.

. BEFORE USE

Items Supplied

Please check that the article is complete as specified in the scope of delivery. If parts are missing, please contact our service center or the sales outlet where you made your purchase at the latest within 5 working days after purchasing the product and upon presentation of a valid bill of purchase. Also, refer to the warranty table in the service information at the end of the operating instructions.

- Open the packaging and take out the equipment with care.
- Remove the packaging material and any packaging and/or transportation braces (if available).
- · Check to see if all items are supplied.

SETUP & PREPARATION

- Inspect the equipment and accessories for transport damage.
- If possible, please keep the packaging until the end of the guarantee period.

The equipment and packaging material are not toys. Do not let children play with plastic bags, foils or small parts. There is a danger of swallowing or suffocating!

Proper Use

The equipment is designed for the grinding/sanding of wood, iron, plastic and similar materials using the appropriate grinding/sanding paper. The machine is not suitable for wet grinding/sanding.

The equipment is to be used only for its prescribed purpose. Any other use is deemed to be a case of misuse. The user / operator and not the manufacturer will be liable for any damage or injuries of any kind caused as a result of this.

Please note that our equipment has not been designed for use in commercial, trade or industrial applications. Our warranty will be voided if the machine is used in commercial, trade or industrial businesses or for equivalent purposes.

Caution!

Residual risks

Even if you use this electric power tool in accordance with instructions, certain residual risks cannot be rules out. The following hazards may arise in connection with the equipment's construction and layout:

- 1. Lung damage if no suitable protective dust mask is used.
- 2. Damage to hearing if no suitable ear protection is used.
- 3. Health damage caused by hand-arm vibrations if the equipment is used over a prolonged period or is not properly guided and maintained.

The dust generated when working with the machine may be

- Always wear goggles and a dust mask when carrying out sanding/grinding work.
- Everybody who uses the machine or enters the workplace must wear a dust mask
- Do not eat, drink or smoke at the workplace.
- Do not use the machine on paints which contain lead.

2. CHANGING SANDING BASES

ENSURE THE TOOL IS DISCONNECTED FROM THE POWER SUPPLY BEFORE PERFORMING ANY OF THE FOLLOWING OPERATIONS..


The Multi Sander comes with 3 sanding bases that can be fitted to the tool, including:

- Circular random orbital sanding base (125mm)
- Triangular detail sanding base (145x100mm) Rectangular 1/3 sheet sanding base (183x91mm)


Removing Sanding Bases

Note: Before removing or fitting the sanding bases, any sandpaper must be removed so that you can access the mounting screws.

1 Remove the 4 screws from the base of the sanding pad by rotating anti-clockwise.




2 Pull the sanding base and aligning pins away from the tool to remove. Note: The base aligning pins can sometimes get stuck in the base of the tool.




Fitting Sanding Bases

1 Place the sanding base onto the tool, aligning the mounting holes and the aligning pins. Note: The circular sanding base




2 Tighten the 4 screws into the base of the sanding pad to secure in place.




3. FITTING SANDING PAPER

Hook and Loop Paper Fitment

sanding pad and then press onto the pad.




- 3 Replace hook & loop backing pad when worn (see



1/3 Sheet Sanding Clamp System

to allow for fitting 1/3 sheet sanding paper that does not have hook and loop fitment.

1 Unhook one of the clamp springs and insert the front of the sand paper, ensuring the holes in the paper align with the holes in the pad.




2 Lock the clamp spring spring, ensuring the paper is pulled tightly.


4. DUST CANISTER

1 Align the holes on the sanding sheet with the holes on the


- 2 Replace the sanding sheet when it is worn.
- maintenance section).



The rectangular sheet sanding pad also features a clamping system




and repeat for the 2nd




Installing

1 Ensure that the lid is pressed tightly onto the container. Note: You should hear a click once fitted correctly.




2 Push the dust canister hard onto the dust extraction port. Note: You should hear a click once fitted correctly.




Emptying


1 Empty dust canister when it becomes 1/3 full for optimum dust extraction.



2 Position over a bin and press the release tab at the top of the lid. Then pull the dust canister away from the extraction



3 To empty, lift the lid of the dust canister over a bin and then Note: Ensure the lid is secured tightly back onto the container



extraction port until it clicks into place.



after emptying.


FOR HEALTH REASONS IT IS MPERATIVE THAT YOU USE THE DUST BAG OR A

5. CONTROLS



On/Off Switch

1 To switch the tool on, press the on/off switch forward into the on position.




2 To stop the tool on, press the on/off switch backward into the off position.



Variable Speed Dial


1 To increase the speed of the tool, rotate the variable speed dial to a higher number.






6. SANDING


1 Secure the material to be sanded.




2 Firmly grasp the sander and turn the sander on.




3 Let the motor build up to maximum speed. Gradually lower it onto the workpiece with a slight forward movement.



4 For optimum results, use either of these strokes.







CAUTION: GUIDE THE POWER CORD DURING SANDING TO PREVENT IT BEING CAUGHT ON THE WORKPIECE OR OTHER OBJECTS.

5 Upon completion of the sanding operation, remove the sander from the workpiece and then turn off the sander.

