

ozito

GLUE GUN KIT


30W 11mm

INSTRUCTION MANUAL

SPECIFICATIONS

Input:	220-240V ~ 50Hz
Pre-Heating Time:	5min
Heating Power:	200W
Operating Temp.:	195°C
Glue Stick Diameter:	11mm
Glue Stick Length:	100mm
Weight:	0.3kg


ozito.com.au




STANDARD EQUIPMENT



Glue Gun



Nozzles



Glue Sticks



Kit Box

3 YEAR REPLACEMENT WARRANTY

GGK-030

WARRANTY

IN ORDER TO MAKE A CLAIM UNDER THIS WARRANTY YOU MUST RETURN THE PRODUCT TO YOUR NEAREST BUNNINGS WAREHOUSE WITH YOUR BUNNINGS REGISTER RECEIPT. PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

Australia 1800 069 486

New Zealand 0508 069 486

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. A CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE.

The benefits provided under this warranty are in addition to other rights and remedies which are available to you at law.

Our goods come with guarantees that cannot be excluded at law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Generally you will be responsible for all costs associated with a claim under this warranty, however, where you have suffered any additional direct loss as a result of a defective product you may be able to claim such expenses by contacting our customer service helpline above.

3 YEAR REPLACEMENT WARRANTY

Your product is guaranteed for a period of **36 months from the original date of purchase**. If a product is defective it will be replaced in accordance with the terms of this warranty. Warranty excludes consumable parts, for example: grinding discs, carbon brushes, disc guard, flange.

WARNING


The following actions will result in the warranty being void.

- If the tool has been operated on a supply voltage other than that specified on the tool.
- If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- Failure to perform maintenance as set out within the instruction manual.
- If the tool is disassembled or tampered with in any way.

KNOW YOUR PRODUCT


GLUE GUN KIT

- 1 Nozzle Cover
- 2 Monitoring Window
- 3 Glue Stick Inlet
- 4 Glue Stick
- 5 Flow Control Trigger
- 6 Support Stand



ACCESSORIES

- 7 Glue Sticks x 4
- 8 Standard Nozzle
- 9 Profiled Nozzle
- 10 Long-Nosed Nozzle



ONLINE MANUAL

Scan this QR Code with your mobile device to take you to the online manual.



SETUP & PREPARATION


1. CHANGING NOZZLES

WARNING! ENSURE THE TOOL IS SWITCHED OFF AND ALLOWED TO COOL DOWN BEFORE PERFORMING ANY OF THE FOLLOWING TASKS.

Installing New Nozzles

The nozzle on this glue gun can be changed to better suit the task at hand.


- 1 Remove the rubber Nozzle Cover by pulling it off the glue gun.



- 2 Unscrew the Nozzle by turning it anti-clockwise with a 13mm spanner (not supplied).

Note: Inspect the rubber O-Ring on the Nozzle for damage before fitting it. If the O-Ring is worn, replace it before continuing to use the Nozzle.

- 3 Fit the desired Nozzle onto the end of the glue gun and tighten it by turning it clockwise.



- 4 Fit the Nozzle Cover back onto the new Nozzle.


3 YEAR REPLACEMENT WARRANTY

OPERATION


2. LOADING GLUE STICKS

Installing Glue Sticks

- 1 Insert the Glue Stick into the Glue Stick Inlet.



- 2 Squeeze the Flow Control Trigger multiple times to push the Glue Stick down.




3. CONTROLS

Flow Control Trigger

The flow rate of the glue is dependent on how much pressure is applied to the Flow Control Trigger.

- 1 Squeeze the Flow Control Trigger to release the glue.



Note: Ensure the Glue Sticks are heated fully to allow an even flow of glue.

- 2 To stop the flow of glue from the gun, release the Flow Control Trigger.

WARNING! ALWAYS REST THE GLUE GUN ON ITS SUPPLIED SUPPORT STAND DURING AND AFTER USE.

CAUTION! THE GLUE GUN WILL REMAIN HOT FOR A FEW MINUTES AFTER USE. DO NOT STORE THE GLUE GUN DIRECTLY AFTER USE. ALLOW THE GLUE GUN TO COOL AND THE GLUE TO SOLIDIFY BEFORE STORING.

4. GLUING


CAUTION! THE TOOL IS RECOMMENDED FOR USE WITH A RESIDUAL CURRENT DEVICE WITH A RATED RESIDUAL CURRENT OF 30mA OR LESS.

Applying Glue

Turn on the glue gun by plugging it into a mains powered outlet. Allow the glue gun to heat up for approximately 5 minutes before use.

CAUTION! THE GLUE GUN HOUSING BETWEEN THE NOZZLE AND HANDLE MAY BECOME HOT DURING USE. THIS IS PERFECTLY NORMAL, HOWEVER AVOID PROLONGED CONTACT WITH THE AREA UNTIL THE GLUE GUN HAS COOLED DOWN.

- 1 Hold the Nozzle against the surface to be glued and press the Flow Control Trigger to deposit glue.



- 2 Press both surfaces together immediately and apply pressure. Hold for 30 seconds to allow the glue to set.

WARNING! THE GLUE GUN NOZZLE AND HEATED GLUE GUN BECOME HOT WHILE IN USE. IN THE EVENT OF ACCIDENTAL SKIN CONTACT WITH HOT GLUE, RUN UNDER COLD WATER IMMEDIATELY.

WARNING! DO NOT ALLOW HOT GLUE TO COME INTO CONTACT WITH THE PRODUCT HOUSING DURING USE.

MAINTENANCE

 **WARNING!** ENSURE THE TOOL IS SWITCHED OFF AND UNPLUGGED BEFORE PERFORMING ANY OF THE FOLLOWING TASKS.

Cleaning

- When not in use, the glue gun should be stored in a dry, frost free location, keep out of children's reach.
- Keep the air vents and motor housing free of dirt and dust as far as possible. Wipe equipment with a clean cloth or blow it with compressed air at low pressure.
- It is recommended that the tool is cleaned immediately after each use.
- Do not use cleaning agents or solvents; these could attack the plastic parts of the equipment.
- Ensure that no water can seep into the device. Ingress of water into an electric tool poses the risk of electric shock.

Note: Ozito Industries will not be responsible for any damage or injuries caused by repair of the glue gun by an unauthorised person or by mishandling.

Power Supply Cords

If the replacement of the supply cord is necessary, this has to be done by the manufacturer or his agent in order to avoid a safety hazard.

SPARE PARTS

Spare parts can be ordered from the Special Orders Desk at your local Bunnings Warehouse.

For further information, or any parts not listed here, visit

www.ozito.com.au or contact Ozito Customer Service:

Australia 1800 069 486

New Zealand 0508 069 486

E-mail: enquiries@ozito.com.au

DESCRIPTION OF SYMBOLS

	Volts		Hertz
	Alternating current		Watts
	Revolutions or reciprocation per minute		No load speed
	Double insulated		Regulator compliance mark
	Wear eye protection		Read instruction manual
	Always wear ear, eye and safety mask		Always wear gloves
	Hot surface; do not touch		

CARING FOR THE ENVIRONMENT



Power tools that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.



ELECTRICAL SAFETY

The electric motor has been designed for 230V and 240V only. Always check that the power supply corresponds to the voltage on the rating plate.

Note: The supply of 230V and 240V on Ozito tools are interchangeable for Australia and New Zealand.



This tool is double insulated; therefore no earth wire is required.

If the supply cord is damaged, it must be replaced by an electrician or a power tool repairer in order to avoid a hazard.

Note: Double insulation does not take the place of normal safety precautions when operating this tool. The insulation system is for added protection against injury resulting from a possible electrical insulation failure within the tool.

Using an Extension Lead

Always use an approved extension lead suitable for the power input of this tool. Before use, inspect the extension lead for signs of damage, wear and ageing. Replace the extension lead if damaged or defective.

When using an extension lead on a reel, always unwind the lead completely. Use of an extension lead not suitable for the power input of the tool or which is damaged or defective may result in a risk of fire and electric shock.



GENERAL POWER TOOL SAFETY WARNINGS



WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1. Work area safety

- Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2. Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.

3. Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- Use personal protective equipment. Always wear eye protection.** Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your

finger on the switch or energising power tools that have the switch on invites accidents.

- Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
 - Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
 - Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
 - If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
 - Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a second.
- ## 4. Power tool use and care
- Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
 - Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
 - Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
 - Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
 - Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
 - Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
 - Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
 - Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.
- ## 5. Service
- Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.



GLUE GUN SAFETY INSTRUCTIONS



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Young children should be supervised to ensure that they do not play with the appliance.

This tool must be placed on its stand when not in use.

Safety Tips

- Be careful when using the appliance in places where there are combustible materials;
- Do not apply to the same place for a long time;
- Do not use in the presence of an explosive atmosphere;
- Be aware that heat may be conducted to combustible materials that are out of sight;

- Place the appliance on its stand after use and allow it to cool down before storage;
- Do not leave the appliance unattended when it is switched on.
- Do not touch hot glue.
- Do not leave glue gun unattended while in use or directly after use.
- Do not touch the nozzle end of the gun while in use or directly after use.
- Do not inhale vapours generated while in use.
- Do not attempt to feed any other materials through the glue gun, eg. crayons, sealants, candles etc.

Recommendations for the use of a residual current device with a rated residual current of 30mA or less.

Ensure the area is well ventilated.